



How to find your Mellanox Serial Number

Find out the Mellanox ConnectX-5 serial number on the server you want to activate by going to device manager in windows, find Mellanox ConnectX-5 and open properties.

Your Mellanox serial number will begin with the letters MT or MTK and will be either 12 or 13 digits long.

